

# JTECH<sup>®</sup>



# User Manual

Foldable LED Digital Poster

# Product Overview

This foldable LED digital poster is a portable, high-definition display designed for smart control and versatile advertising or information sharing.

Its collapsible design ensures easy transport and quick setup, making it perfect for hospitality, retail, trade shows, outdoor events, and a variety of other venues.



## Safety Instructions

- Read this manual carefully before use and keep it for future reference.
- Make sure the supply voltage matches the unit's rated voltage and use a properly grounded outlet.
- Keep the unit away from rain, moisture, and high temperatures to avoid damage.
- Disconnect power before folding, unfolding, or moving the unit to ensure personal safety.


# Installation Steps

- Open the package and verify all accessories are present (power cord, manual, support legs).
- Lay the device on a flat surface, release the latches, and unfold it slowly until fully upright.
- Attach and tighten the support legs to stabilize the unit.






Open the side panels on both sides to begin splicing the individual posters.



Push the poster displays together one by one.



Tighten the connector, loosen the connector



Lock



Unlock




Tighten the 5 units one by one to achieve a seamless splicing into a complete LED screen.

# Operating Guide


Mobile Control: Scan the QR code in this manual to install the dedicated app; once paired, you can cast content wirelessly and edit playlists.

Use a computer to connect the screens. Connect the power cables to all 5 units in sequence, daisy-chain the 4 HDMI cables, and use one main network cable for system connection and debugging.

USB Playback: Insert a USB drive; the system will detect and loop media files automatically. (Only 1 piece)



4pcs HDMI cables




5pcs Power cable




1pcs Main network cable

# Cables



# Example of Hardware Connections



# Device Operation

## Step One

Open Vortex Handy

Tap Add Device on the Home Page

## Step Two

Connect to the Wi-Fi AP of the starting device. Refer to Page 9 for an example of hardware connections to ensure your phone and the devices are on the same LAN.

## Step Three

In the Devices list, find the device and tap Connect.

## Step Four

Enter the Password and tap Connect. The default password can be found on the device's SSID label.

