
# 43" A Frame Indoor or Outdoor LCD Display


**User Manual** 












## What's in the Box



- Outdoor Digital A-Frame Unit with Android and Built-In Battery
- Charger and Power Cord
- Key to Maintenance Door

## **Unpacking Notice**

## **Before Unpacking**















- Please read and fully understand unpacking notice before installation.
- Please check the packaging for any abnormalities, such as creaking, dents, etc.
- Please do necessary inspection before you move the display out of the carton.
- Always have an experienced technician in stall the display to prevent any damage.

### Unpacking












- This product is packed in a carton, together with the standard accessories.
- Any other optional accessories will be packed separately.
- After opening the carton, ensure that the contents are complete and in good condition.
- As this product is high and heavy, the operation of moving the device is recommended to be performed by two technicians.

# **Details**





# Moving the Display

1

#### **EXPAND THE STAND**

- Put the device vertically
- Hold the handle with both hands and unfold the retention bracket to stand



2

RELEASE THE LOCKING BAR TO START MOVING THE UNIT



3

GRASP THE HANDLE AT THE REAR OF THE UNIT AND TILT THE DISPLAY IN A BACKWARD DIRECTION




4

PUSH THE UNIT TO THE INTENDED LOCATION, ENSURING THAT THE BOTTOM PART OF THE SCREEN REMAINS CLEAR OF THE FLOOR



# **Charging the Battery**

This display incorporates an internal rechargeable lithium - polymer battery. At the time of its arrival, the battery will already possess a certain amount of charge. Nevertheless, in order to charge the battery to its full capacity, it is necessary to connect the charger (or the mains power cable) to both the display and the mains socket.



#### Instructions

1 CONNECT THE POWER PLUG TO THE CHARGING UNIT



2 CONNECT THE CHARGING UNIT TO THE DISPLAY



CONNECT THE POWER PLUG TO THE OUTLET



#### **Charging Light Mode**



**CHARGING MODE** 



**FULLY CHARGED** 

#### **Charge Level Indicator**




THE SMART METER ON
THE REAR OF THE
DISPLAY

## **Connect the WiFi**



## **USB Plug & Play**



\*This file is only required when there is a need to delete old content.

#### **SPECIFICATIONS**

**Model Number** LSR13001041 LSR13001043 43inch 43inch Panel 1920\*1080 1920\*1080 LCD Panel Type Resolution **LED** LED Backlight 1500 nits 2500 nits **Brightness** 1200:1 1200:1 **Contrast Ratio** 8 bits 8 bits Color Depth Response Time 8 ms (typ) 8 ms (typ) 178° / 178° 178° / 178° Viewing Angle 50,000 hrs (typ.) 50,000 hrs (typ.) Light Life Time

Power Charger with power input 110V or 220V, 50 Hz / 60 Hz

Rechargeable Battery 43.2Ah battery capability 62.4Ah battery capability

Charing time 4.5 hours 8 hours **Power Consumption** <98W <135W

**User Interface** 

Language English / Multi Language option **Environment** 

**Operating Temperature** -20°C ~ 60°C Storage Temperature -10°C ~ 60°C

Humidity 10% ~ 80% RH Non-condensing

ARM Quad-Core Cortex-A55 up to 1.9GHz Processor

2GB DDR3 Main memory Mali-G31 GPU **Interface Graphics** 

eMMC 16GB(about 2GB occupied by o/s) Storage (FDM) Multimedia

IO ports 265; Encoder: 1080P 100fps H.265/H.264 USB 2.0 x2, RJ45 x 1, HDMI in

Android 9.0

Operating system

**Network Environment** 

WLAN 802.11 b/g/n (2.4GHz), RJ45 Certification

CE, FCC&Rohs **Mechanical Specs Portrait** Orientation **Black** Cabinet Color 54.3x11x28.1

49.5x23.4x7.1 49.5x23.4x7.2 CTN Dimension (LxHxD) (Inches)

Weight (N.W) 95 lb 104 lb Weight (G.W/ Carton) 106 lb 126 lb



Product Dimension (LxHxD) (Inches)

**Internal Player** 



