

Components

- Push Button Transmitter
- Rugged Pagers (PGRGDM/PGRGDS)
- Charging Base (with power supply)



Equipment Setup

Step 1 – Push Button Setup

Place the Push Button Transmitter in a convenient location (Table, Counter) away from heat and humidity. (See Page 2 for more installation information)



Top



Bottom




Table or
Location
Name

Step 2 – Pager

Plug the power supply into the charging base and then into a standard 110-240v outlet. A surge protector is highly recommended. Place Pager(s) into Charging Station. When charging they will display a blue light.

System Operation

Placing the Push Button Transmitters:

Place transmitters in a convenient location wherever you need them. You can simply set the transmitter on a counter or table, or you can Velcro it down to secure it. These transmitters can still have their batteries replaced with properly installed Velcro on the bottom side of the transmitter.

Handing out the pagers:

Give the staff member a pager. Tell the staff member the pager will alert when they are needed. The default page for this system is programmed for the pager to vibrate for 8 seconds. After the pager is finished vibrating it automatically goes back into standby mode waiting for the next page. Hand the pagers out from the charging base (they will “demo” page each time they are removed from the stack). A fully charged pager will function all day without being recharged.

System Operation Cont.

Paging the Pager:

Push Button Transmitters come with 1 or 3 buttons. Press one of the buttons and the page will be sent to the corresponding pager. A red light will display for two seconds indicating a successful page.

Example:

If you push the #3 button on Push Button Transmitter #3, the corresponding pager (Shown below) will display a message “Manager to Table 3”



Attaching to Surface

- Remove the paper backing from one side of the included double-sided foam adhesive.
- Attach the foam adhesive to the back of the push-button transmitter.
- Remove the remaining paper backing from the other side of the foam adhesive.
- Firmly press the transmitter onto the desired table or wall surface.
- [Click for Instructional Video](#)



Optional Holder – Clear or Black (Sold Separately)

- Create 2” x 2” Button Label
- Open Holder – Splits into two halves.
- Place Label using indent guides between the top and bottom.
- Place or adhere button in the space provide.
- Align the top and bottom to enclose label between.
- [Click for Instructional Video](#)